



# CBI SAFETY STANDS OWNER'S MANUAL

## Attachment Information

Model Number: \_\_\_\_\_

Description: \_\_\_\_\_

Part Number: \_\_\_\_\_

Date Shipped: \_\_\_\_\_

## Forklift Information

Model Number: \_\_\_\_\_

Capacity: \_\_\_\_\_

Mounting Class: \_\_\_\_\_

### Safety:

- Inspect for damage before use.
- Always engage emergency brake while using safety stands.
- When placing safety stands, keep hands and feet free from dangerous positions and pinch points.
- Do not use the stands for any other purpose than indicated.
- Make sure cover caps are oriented properly on the stand. Improper positioning can compromise stability.
- Cover caps are not for use without safety stands.

### Preventative Maintenance

CBI Safety products have been constructed to require very little attention. But there are some measures which can be taken to ensure the long life of your CBI Equipment. Perform these tasks before each use.

- Visual inspection for cracked welds
- Check for damage from previous use.
- Store unit out of the elements.

### Warranty:

CBI safety stands are warranted for 30 days. Products are guaranteed to be free from defects in material and workmanship and that, if the equipment or any part thereof is returned to an authorized dealer, transportation charges prepaid, and, if examination discloses to its satisfaction that the said equipment, part or parts has been defective in workmanship or material, CBI will deliver to purchaser without charge, transportation prepaid, parts of first class workmanship and material in exchange for any parts so found to be defective and its obligation is limited to said exchange. CBI shall not be liable for any repairs or alterations except those made with its written consent and shall not be liable for damages from delay or loss of use or for other indirect or consequential damages, losses or expenses of any kind. It is specifically agreed that the liability of CBI under all guarantees, either express or implied, is strictly limited to those terms as hereinbefore provided.

### Repairs and required maintenance:

Attachments should not be disassembled without first consulting your authorized CBI Attachments dealer. Replacement parts are available, and are listed in the pages that follow.

### Service and Support:

We are here to help. For information about parts, service, or a warranty claim, call 1-800-547-3131 or reach us through email at [customerservice@cbimfg.com](mailto:customerservice@cbimfg.com)



# CBI SAFETY STANDS OWNER'S MANUAL

## BEFORE USAGE

1. Plan ahead. Be sure you have plenty of space, and that the forklift will be out of the way before putting it on safety stands
2. All national and regional safety standards must be followed. All required safety equipment is to be used when performing this action (e.g., safety gloves, boots, etc.).
3. Make sure the safety stands are not damaged, bent, or cracked.
4. Engage parking brake and chalk wheels before lifting forklift

## USAGE

1. Use a recommended method to raise the forklift.
2. Position safety stands directly centered under tires - do not use cover caps when using stands under tires.
3. Position stands with cover caps under frame. Stands should be all the way under the frame, as far apart as possible for maximum stability.

## WARNINGS

1. Do not use different sized stands on one lift.
2. Do not use stands with cover caps under wheels.
3. Do not position stands partially under forklift.

## NOTES

1. Compliance with laws, regulations, codes, and non-voluntary standards enforced in the location where the attachment is used is exclusively the responsibility of the owner/end-user.
2. CBI is not liable for any injury or property damage that occurs as a result of failing to apply the instructions in this manual and information on product/forklift tags.

